

Work Order ID 130318

March-05-15 9:48:30 AM

SHIP TODAY March 5
130318

Page 1

Item ID: DSI 9594-011

Accept

N900040100

Setup Start *NS1*

Revision ID:

Item Name: Fwd Ground Handling Spacer

Stop *NS2*

Start Date: 3/05/15 Start Qty: 1.00

1

Cust Item ID:

Required Date: 3/05/15 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals: Process Plan: W Date: _____ Tooling: _____ Date: _____
QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Run Start *NR1*
Stop *NR2*

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr
DSI 9594	B

100	Document Control	0.00							
100	DOCUMENT CONTROL								
DC	Memo	0.00							
Doc.Control -USB or Paperwork	Photocopy bluefile & type labels per PPP DSI 9594-011 CHG002								

MCS 1503-05

110	Pick Kit	0.00							
-----	----------	------	--	--	--	--	--	--	--

110									
Packaging	Memo	0.00							

Packaging

DAS
20
9-89

MAR 06 2015

DAS
06
9-89

120	QC4-100% Inspect kits for completeness	0.00							
-----	--	------	--	--	--	--	--	--	--

120									
QC	Memo	0.00							

Quality Control

(IX)

DAS
46
9-89

MAR 06 2015

Work Order ID 130318

March-05-15 9:48:30 AM

130318

Page 2

Item ID: DSI 9594-011 Accept ***N900040100*** Setup Start ***NS1***
 Revision ID: Stop ***NS2***
 Item Name: Fwd Ground Handling Spacer
 Start Date: 3/05/15 Start Qty: 1.00 ***1*** Cust Item ID:
 Required Date: 3/05/15 Req'd Qty: 1.00 ***1*** Customer:
 Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____ Run Start ***NR1***
 QC: _____ Date: _____ SPC (Y/N): _____ Date: _____ Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130	Packaging	0.00							
130									
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP DSI 9594-011								
	Location: <i>Shy</i>								
140	QC21- Final Inspection - Work Order Release	0.00							
140									
QC	Memo	0.00							
Quality Control									

(1x)

DAS
46
9-89

MAR 06 2015

MC 1503-06

U1503.06

Picklist Print

March-05-15 9:48:30 AM

Page 1

Work Order ID: 130318

130318

Parent Item: DSI 9594-011

DSI 9594-011

Parent Item Name: Fwd Ground Handling Spacer

Start Date: 3/05/15

Required Date: 3/05/15

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP REV:A 12.02.27 NEW ISSUE DD VERF:EC
13.03.19 AS PER DSI REV.B DD VERF:JLM

IPP REV:B

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D2579 *D2579* Crossbolt Spacer	DAS 46 9-89	Manufactured	No			110	Each	208.0000	4	4			

Location	Loc Qty	Loc Code
LG001	208	
113785	24	
123997	184	

MS24694-C52

Purchased

No

110

Each

115.0000

4

4

MS24694-C52

SCREW

DAS
46
9-89

Location	Loc Qty	Loc Code
FP001	65	
m127059	65	
ST287	50	
124308	50	

SP/15-35